

LIST OF PRINTER USABLE WITH ABX e-SAT MODULE

- ◆ "Brother, page 2"
- ◆ "Canon, page 4"
- ◆ "Epson, page 5"
- ◆ "Generic, page 7"
- ◆ "HP, page 8"
- ◆ "Kyocera, page 11"
- ◆ "Minolta, page 14"
- ◆ "Okidata, page 15"
- ◆ "Samsung, page 16"
- ◆ "Xerox, page 17"
- ◆ "Other, page 18"

Brother

Printer	Driver
Brother DCP-1200	ljet2p
Brother HL-4Ve	laserjet
Brother HL-8	ljetplus
Brother HL-10h	ljet4
Brother HL-10V	ljet3
Brother HL-630	ljet2p
Brother HL-660	ljet4
Brother HL-760	ljet4
Brother HL-960	ljet4
Brother HL-1040	ljet2p
Brother HL-1050	ljet4
Brother HL-1060	ljet4
Brother HL-1070	ljet4
Brother HL-1240	laserjet
Brother HL-1250	lj5 mono, lj5gray, ljet4
Brother HL-1260	ljet4
Brother HL-1270N	lj5 mono, lj5gray, ljet4
Brother HL-1430	ljet4
Brother HL-1440	ljet4
Brother HL-1450	lj5 mono, lj5gray, ljet4
Brother HL-1470N	lj5 mono, lj5gray, ljet4
Brother HL-1650	lj5 mono, lj5gray, ljet4d, ljet4
Brother HL-1660e	lj5 mono, lj5gray, ljet4d, ljet4
Brother HL-1670N	lj5 mono, lj5gray, ljet4d, ljet4
Brother HL-1850	lj5 mono, lj5gray, ljet4d, ljet4

Printer list

Brother

Printer	Driver
Brother HL-1870N	lj5 mono, lj5gray, ljet4d, ljet4
Brother HL-2060	lj5 mono, lj5gray, ljet4
Brother HL-2400CeN	lj5 mono, lj5gray
Brother HL-2460	lj5 mono, lj5gray
Brother HL-2460N	lj5 mono, lj5gray
Brother HL-2600CN	lj5 mono, lj5gray
Brother HL-3400CN	lj5 mono, lj5gray
Brother HL-3450CN	lj5 mono, lj5gray
Brother HL-4000CN	lj5 mono, lj5gray
Brother HL-5030	lj5 mono, lj5gray, ljet4
Brother HL-5040	lj5 mono, lj5gray, ljet4
Brother HL-5050	lj5 mono, lj5gray, ljet4
Brother HL-5070N	lj5 mono, lj5gray, ljet4
Brother HL-5140	lj5 mono, lj5gray, ljet4
Brother HL-5150D	lj5 mono, lj5gray, ljet4
Brother HL-5170DN	lj5 mono, lj5gray, ljet4
Brother HL-7050	lj5 mono, lj5gray
Brother HL-7050N	lj5 mono, lj5gray
Brother MFC-6550MC	ljet2p
Brother MFC-8300	laserjet, ljet3
Brother MFC-9500	ljet2p
Brother MFC-9600	ljet2p

Canon

Printer	Driver
Canon GP 335	ljet4
Canon imageRunner 330s	ljet4
Canon LBP-4sx	ljet3
Canon LBP-430	ljet3, ljet4
Canon LBP-1000	lj5mono, lj5gray, ljet4
Canon LBP-1260	ljet4
Canon LBP-1760	lj5mono, lj5gray, ljet4

Epson

Printer	Driver
Epson ActionLaser II	laserjet
Epson ActionLaser 1100	ljet3
Epson AcuLaser C1900	ljet4
Epson AcuLaser C1900PS	ljet4
Epson AcuLaser C2000	lj5mono, lj5gray, ljet4
Epson AcuLaser C2000PS	lj5mono, lj5gray, ljet4
Epson AcuLaser C4000	ljet4
Epson AcuLaser C4000PS	ljet4
Epson AcuLaser C4100	ljet4
Epson AcuLaser C4100PS	ljet4
Epson AcuLaser C8500	lj5mono, lj5gray, ljet4
Epson AcuLaser C8500PS	lj5mono, lj5gray, ljet4
Epson AcuLaser C8600	lj5mono, lj5gray, ljet4
Epson AcuLaser C8600PS	lj5mono, lj5gray, ljet4
Epson EPL-5200	ljet3
Epson EPL-5200+	ljet3
Epson EPL-5700	ljet4
Epson EPL-5800	lj5mono, lj5gray, ljet4
Epson EPL-5800PS	lj5mono, lj5gray, ljet4
Epson EPL-5900	lj5mono, lj5gray, ljet4
Epson EPL-5900PS	lj5mono, lj5gray, ljet4
Epson EPL-6100	lj5mono, lj5gray, ljet4
Epson EPL-6100PS	lj5mono, lj5gray, ljet4
Epson EPL-7100	laserjet
Epson EPL-N1600	ljet4

Printer	Driver
Epson EPL-N1600PS	ljet4
Epson EPL-N2050	lj5mono, lj5gray, ljet4
Epson EPL-N2050+	lj5mono, lj5gray, ljet4
Epson EPL-N2050PS	lj5mono, lj5gray, ljet4
Epson EPL-N2050PS+	lj5mono, lj5gray, ljet4
Epson EPL-N2120	lj5mono, lj5gray, ljet4
Epson EPL-N2500	lj5mono, lj5gray, ljet4
Epson EPL-N2500PS	lj5mono, lj5gray, ljet4
Epson EPL-N2750	lj5mono, lj5gray, ljet4
Epson EPL-N2750PS	lj5mono, lj5gray, ljet4

Generic

Printer	Driver
Generic PCL 4 Printer	laserjet, ljet2p, ljetplus
Generic PCL 5 Printer	ljet3, ljet3d
Generic PCL 5c Printer	ljet4d, ljet4
Generic PCL 5e Printer	ljet4d, ljet4
Generic PCL 6/PCL XL Printer	lj5mono, lj5gray, ljet4d, ljet4

HP

Printer	Driver
HP Color LaserJet 4550	lj5mono, lj5gray, ljet4
HP Color LaserJet 4600	lj5mono, lj5gray, ljet4
HP Color LaserJet 5000	ljet4
HP DeskJet	Deskjet
HP DeskJet 200	Deskjet
HP DeskJet 320	djet500
HP DeskJet 340C	Deskjet
HP DeskJet 500	djet500
HP DeskJet 510	djet500
HP DeskJet 520	djet500
HP DeskJet 540C	djet500
HP DeskJet 550C	djet500
HP DeskJet 600	djet500
HP DeskJet Plus	Deskjet
HP LaserJet	laserjet
HP LaserJet Plus	ljetplus
HP LaserJet 2	laserjet
HP LaserJet 2D	ljet2p
HP LaserJet 2P	ljet2p
HP LaserJet 2P Plus	ljet2p
HP LaserJet 3	ljet3
HP LaserJet 3D	ljet3d
HP LaserJet 3P w/PS	ljet3, ljet3d
HP LaserJet 3P w/ PCL5	ljet4
HP LaserJet 4	ljet4

Printer	Driver
HP LaserJet 4 Plus	ljet4
HP LaserJet 4L	ljet4
HP LaserJet 4M	ljet4d, ljet4
HP LaserJet 4ML	ljet4
HP LaserJet 4P	ljet4
HP LaserJet 4Si	ljet4d, ljet4
HP LaserJet 4V	ljet4
HP LaserJet 5	lj5mono, lj5gray, ljet4
HP LaserJet 5L	ljet4
HP LaserJet 5P	ljet4
HP LaserJet 5Si	lj5mono, lj5gray, ljet4
HP LaserJet 6	lj5mono, lj5gray, ljet4
HP LaserJet 6L	ljet4
HP LaserJet 6P	ljet4
HP LaserJet 1015	ljet4
HP LaserJet 1100	ljet4
HP LaserJet 1100A	ljet4
HP LaserJet 1150	ljet4
HP LaserJet 1200	lj5mono, lj5gray, ljet4
HP LaserJet 1220	lj5mono, lj5gray, ljet4
HP LaserJet 1300	lj5mono, lj5gray, ljet4
HP LaserJet 2100	lj5mono, lj5gray, ljet4
HP LaserJet 2100M	lj5mono, lj5gray, ljet4
HP LaserJet 2200	lj5mono, lj5gray, ljet4
HP LaserJet 2300	lj5mono, lj5gray, ljet4
HP LaserJet 3200	lj5mono, lj5gray, ljet4
HP LaserJet 3200m	lj5mono, lj5gray, ljet4
HP LaserJet 3200se	lj5mono, lj5gray, ljet4

Printer	Driver
HP LaserJet 3300 MFP	lj5mono, lj5gray
HP LaserJet 3310 MFP	lj5mono, lj5gray
HP LaserJet 3320 MFP	lj5mono, lj5gray
HP LaserJet 3320N MFP	lj5mono, lj5gray
HP LaserJet 3330 MFP	lj5mono, lj5gray
HP LaserJet 4000	lj5mono, lj5gray
HP LaserJet 4050	lj5mono, lj5gray, ljet4
HP LaserJet 4100	lj5mono, lj5gray, ljet4
HP LaserJet 8150	lj5mono, lj5gray, ljet4
HP LaserJet 9000	lj5mono, lj5gray, ljet4
HP OfficeJet	djet500
HP OfficeJet R45	Deskjet
HP OfficeJet 300	djet500
HP OfficeJet 330	djet500
HP OfficeJet 350	djet500
HP OfficeJet LX	djet500

Kyocera

Printer	Driver
Kyocera F-800	laserjet, ljetplus
Kyocera F-800T	laserjet, ljetplus
Kyocera F-820	laserjet, ljetplus
Kyocera F-1000	laserjet, ljetplus
Kyocera F-1010	laserjet, ljetplus
Kyocera F-1200	laserjet, ljetplus
Kyocera F-1200S	laserjet, ljetplus
Kyocera F-1800	laserjet, ljetplus
Kyocera F-2000	laserjet, ljetplus
Kyocera F-2010	laserjet, ljetplus
Kyocera F-2200	laserjet, ljetplus
Kyocera F-2200S	laserjet, ljetplus
Kyocera F-3000	laserjet, ljetplus
Kyocera F-3010	laserjet, ljetplus
Kyocera F-3300	laserjet, ljetplus
Kyocera F-5000	laserjet, ljetplus
Kyocera FS-400	laserjet, ljet3
Kyocera FS-600	ljet4d, ljet4
Kyocera FS-600 (KPD-L-2)	ljet4d, ljet4
Kyocera FS-680	ljet4d, ljet4
Kyocera FS-800	ljet4d, ljet4
Kyocera FS-850	laserjet, ljet3
Kyocera FS-1000	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-1000+	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-1010	lj5mono, lj5gray, ljet4d, ljet4

Printer	Driver
Kyocera FS-1050	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-1200	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-1500	laserjet, ljet3, ljet3d
Kyocera FS-1550	laserjet, ljet3, ljet3d
Kyocera FS-1550+	laserjet, ljet3, ljet3d
Kyocera FS-1600	ljet4d, ljet4
Kyocera FS-1600+	ljet4d, ljet4
Kyocera FS-1700	ljet4d, ljet4
Kyocera FS-1700+	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-1750	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-1800	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-1800+	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-1900	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-3400	laserjet, ljet3, ljet3d
Kyocera FS-3400+	laserjet, ljet3, ljet3d
Kyocera FS-3500	laserjet, ljet3, ljet3d
Kyocera FS-3600	ljet4d, ljet4
Kyocera FS-3600+	ljet4d, ljet4
Kyocera FS-3700	ljet4d, ljet4
Kyocera FS-3700+	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-3750	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-3800	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-5500	laserjet, ljet3
Kyocera FS-5800C	ljet4d, ljet4
Kyocera FS-5900C	ljet4d, ljet4
Kyocera FS-6500	ljet4d, ljet4
Kyocera FS-6500+	ljet4d, ljet4
Kyocera FS-6700	lj5mono, lj5gray, ljet4d, ljet4

Printer	Driver
Kyocera FS-7000	ljet4d, ljet4
Kyocera FS-7000+	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-8000C	ljet4d, ljet4
Kyocera FS-9000	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-9100DN	lj5mono, lj5gray, ljet4d, ljet4
Kyocera FS-9500DN	lj5mono, lj5gray, ljet4d, ljet4
Kyocera KM-1530	lj5mono, lj5gray, ljet4d, ljet4
Kyocera KM-1810	lj5mono, lj5gray, ljet4d, ljet4
Kyocera KM-2030	lj5mono, lj5gray, ljet4d, ljet4
Kyocera KM-2530	lj5mono, lj5gray, ljet4d, ljet4
Kyocera KM-3530	lj5mono, lj5gray, ljet4d, ljet4
Kyocera KM-4230	lj5mono, lj5gray, ljet4d, ljet4
Kyocera KM-4530	lj5mono, lj5gray, ljet4d, ljet4
Kyocera KM-5230	lj5mono, lj5gray, ljet4d, ljet4
Kyocera KM-5530	lj5mono, lj5gray, ljet4d, ljet4
Kyocera KM-6230	lj5mono, lj5gray, ljet4d, ljet4
Kyocera P-2000	laserjet, ljetplus
Kyocera P-2002	laserjet, ljetplus

Minolta

Printer	Driver
Minolta PagePro 6	ljet4
Minolta PagePro 6e	ljet4
Minolta PagePro 6ex	ljet4
Minolta PagePro 8	ljet4
Minolta PagePro 8L	ljet2p
Minolta PagePro 1100	ljet4

Okidata

Printer	Driver
Okidata Okipage 6e	ljet4
Okidata Okipage 6ex	ljet4
Okidata Okipage 8p	ljet4
Okidata Okipage 10e	ljet4
Okidata Okipage 10ex	lj5mono, lj5gray, ljet4
Okidata Okipage 14ex	lj5mono, lj5gray, ljet4
Okidata OL400	laserjet
Okidata OL400e	ljet2p
Okidata OL400ex	ljet2p
Okidata OL410e	ljet4
Okidata OL600e	ljet2p
Okidata OL610e/S	laserjet
Okidata OL800	laserjet
Okidata OL810ex	ljet4
Okidata Super 6e	ljet4

Samsung

Printer	Driver
Samsung ML-85	ljet4
Samsung ML-1250	lj5mono, lj5gray, ljet4
Samsung ML-1450	ljet4
Samsung ML-1450PS	ljet4
Samsung ML-1650	lj5mono, lj5gray, ljet4
Samsung ML-1651N	lj5mono, lj5gray, ljet4
Samsung ML-1750	ljet4
Samsung ML-2150	ljet4d, ljet4
Samsung ML-2150PS	ljet4d, ljet4
Samsung ML-2151N	ljet4d, ljet4
Samsung ML-2151NPS	ljet4d, ljet4
Samsung ML-2152W	ljet4d, ljet4
Samsung ML-2152WPS	ljet4d, ljet4
Samsung ML-2550	ljet4d, ljet4
Samsung ML-2551N	ljet4d, ljet4
Samsung ML-2552W	ljet4d, ljet4
Samsung ML-4600	lj5mono, lj5gray, ljet4
Samsung ML-5000a	ljet4
Samsung ML-6000/6100	ljet4
Samsung ML-7000/7000P/7000N	lj5mono, lj5gray, ljet4
Samsung ML-7050	lj5mono, lj5gray, ljet4
Samsung ML-7300	ljet4d, ljet4
Samsung ML-7300N	ljet4d, ljet4
Samsung QL-5100A	ljet4
Samsung QL-6050	ljet4

Xerox

Printer	Driver
Xerox Able 1406	ljet4
Xerox DocuPrint 4508	ljet4
Xerox DocuPrint N4512	lj5mono, lj5gray, ljet4
Xerox DocuPrint N4512PS	lj5mono, lj5gray, ljet4
Xerox DocuPrint P8e	ljet4
Xerox DocuPrint P12	ljet2p
Xerox DocuPrint P1202	lj5mono, lj5gray, ljet4
Xerox Document Centre 400	ljet4

Other

Printer	Driver
Apple LaserWriter Select 360	ljet2p
Citizen ProJet II	laserjet
DEC 1800	ljet3
DEC DECWriter 500i	djet500
DEC DECwriter 110i	djet500
DEC LN17	ljet4
Fujitsu PrintPartner 10V	laserjet, ljet4
Fujitsu PrintPartner 16DV	ljet4
Fujitsu PrintPartner 20W	lj5mono, lj5gray, ljet4
Fujitsu PrintPartner 8000	ljet3
IBM Infoprint 12	lj5mono, lj5gray, ljet4
IBM Page Printer 3112	ljet4
IBM 4019	laserjet
IBM 4029 030 LaserPrinter 10	laserjet, ljet3
Infotec 4651 MF	lj5mono, lj5gray, ljet4
Lexmark Optra E	ljet4
Lexmark Optra E+	ljet4
Lexmark Optra E321	ljet4
Lexmark Valuewriter 300	ljet2p
Lexmark Winwriter 400	ljetplus
NEC SuperScript 660i	ljet4
NEC SuperScript 860	ljet2p
NEC SuperScript 870	ljet2p
NEC SuperScript 1260	ljet2p
NEC SuperScript 1800	ljet4

Printer list

Other

Printer	Driver
Olivetti JP350S	laserjet
Olivetti PG 306	laserjet
Olivetti JP450	djet500
Panasonic KX-P4410	ljet2p
Panasonic KX-P4450	ljet3
Panasonic KX-P6150	laserjet
Panasonic KX-P6500	ljet2p
PCPI 1030	laserjet
Raven LP-410	ljet2p
Ricoh Aficio 220	lj5mono, lj5gray, ljet4
Ricoh Aficio 401	ljet4
Ricoh Aficio 700	ljet4
Star LS-04	ljet2p
Seiko SpeedJET 200	laserjet
Sharp AR-161	lj5mono, lj5gray, ljet4
Star LaserPrinter 8	laserjet
Tally MT908	ljet3